


Wiring Diagrams


JETFLOW SJ 220V-240V SINGLE PHASE



Wiring Diagrams

JETFLOW SJ 220V-240V SINGLE PHASE C/W EL21

VARIABLE SPEED CONNECTION CONTROLLER TYPE: 149-EL21



Wiring Diagrams

JETFLOW SJ 220V-240V SINGLE PHASE C/W TC

VARIABLE SPEED CONNECTION CONTROLLER TYPE: 149-TC12 149-TC14

